BATTERY 101

IMPORTANT SAFETY INFORMATION:

DO NOT GET YOUR BATTERY / ELECTRICAL SYSTEM WET. THIS SYSTEM IS NOT WATERPROOF! ANY MOISTURE MUST BE DRIED OUT COMPLETELY BEFORE CHARGING OR HISING AGAIN.

THE RANGE OF THE BATTERY IS DEPENDENT ON A NUMBER OF FACTORS INCLUDING: BATTERY AGE, TERRAIN, RIDER HEIGHT/WEIGHT, RIDING STYLE, & TEMPERATURE

THE THROTTLE READS BATTERY VOLTAGE NOT PERCENTAGE

CHARGER INFO:

- · NOT CONNECTED: CHARGER LED IS GREEN (CONSTANT).
- · DURING CHARGING: CHARGER LED IS RED (CONSTANT)
- CHARGING ISSUE: CHARGER LED IS RED (BLINKING)
- CHARGING IS COMPLETED (100%): CHARGER LED IS GREEN (CONSTANT)

CHARGING THE BATTERY:

- THE BATTERY SHOULD BE CHARGED AFTER EVERY RIDE TO MAINTAIN OPTIMAL HEALTH
- CHARGING THE BATTERY SHOULD BE AT ROOM TEMPERATURE (±20°C/68°F). CHARGING BELOW 0°C OR ABOVE 40°C (32°F~104°F) CAN LEAD TO INSUFFICIENT CHARGING AND CAN BE HARMFUL TO THE BATTERY LIFE CYCLE.
- DO NOT PULL ON THE BATTERY CABLES, YOU MUST GRAB THE YELLOW XT60 AND XT90 PLUGS TO UNPLUG AND RE-PLUG YOUR BATTERY.
- THE BATTERY TAKES APPROXIMATELY 5 HOURS TO FULLY CHARGE.



DO NOT GET BATTERY / ELECTRICAL SYSTEM WET



REMOVING BATTERY FROM BIKE

INSURE YOUR BATTERY IS UNPLUGGED BEFORE REMOVING IT



